

## ELECTRICAL HOOK-UP

---



All swim spas require a separate circuit up to 45amps single phase. (3 phase options available on request).

Most swim spas require a 32amp circuit. Please ask your sales representative regarding requirements.

When we arrive to site, we position the spa to your requirement.

Your electrician must pull the "tail" of cable through an entry point into the spas cabinet and make the final connection inside - we advise that you refer them to this guide.

If for any reason whatsoever, the electrical supply is incomplete on our arrival for handover; we will be unable to fulfil the handover procedure, or demonstrate the operation of the hot tub to you. **We cannot connect to or modify the electrical connection in any way**, so you must ensure your electrician completes the work before we arrive.



All new circuits should have an approved RCD (Earth Leakage Breaker) fitted by a qualified Electrician.

**Splashes**  
SPA WORLD